

# Wiring the siren

- Connecting the siren to the alarm panel is a simple process.
- Use a 0.5 mm Ripcord for this connection.
- Connect the RED wire from the siren to the BELL + on the alarm panel.
- Next connect the BLACK wire from the siren to the BELL – on the alarm panel.
- It might be required in some instances to extend the wire between the siren and alarm panel. When this is done the extension points must be soldered and properly insulated.

