

Wiring the keypad

- Connecting the keypad to the alarm panel is done by means of the communication BUS or COMBUS.
- The correct wire to use for connecting the keypad is a 6 core comms cable.
- For the Combus connections we use the following colors:
- **RED** – 12v Positive
- **BLACK** – 12v Negative
- **GREEN** – BUS
- **YELLOW** – BUS
- Start by connecting the **RED** wire to the **AUX +** and **BLACK** to the **AUX -** on the alarm panel.
- Now connect the **GREEN** wire to **GRN** and the **YELLOW** wire to **YEL** on the alarm panel.
- Next connect the **RED**, **BLACK**, **GREEN** and **YELLOW** wires to the corresponding **RED**, **BLK**, **GRN**, and **YEL** points on the back of the keypad.

